

Dr. Fixit Softbase 50

Modified Bitumen Emulsion

Description

Dr. Fixit Softbase 50 is a modified bitumen emulsion comprise of SBP, Neoprene, high grade polymer for waterproofing. When dry, Dr. Fixit Softbase 50 will gain high elasticity and excellent adhesive properties. It can bond with most substrates such as concrete, metal, brick and easy to use.

Area of Application

- Sport courts such as tennis courts

Method of Application

- Substrate preparation
- The substrate must be clean and dust free
- Remove any impurities and loose materials

Application

- Use glass sand No#70/140, 1.5: 1 ratio of Dr.Fixit Soft Base 50
- Mix the sand with Water 1.2litre (Use Water 1.2 litre/ Dr.Fixit Soft Base 50:1set), then for Dr.Fixit Soft Base 50 and mix until homogeneous.
- It to be makes the next layer or each layer. Must allow the first layer to dry for at least 1 day when the skin is completely dry. It must be scrubbed with a housewife scrub and used glass paper number 60/80 to make the skin smooth. It always the thickness increases and each layer thickness Lowest - highest adjustable, not more than 0.5-1 mm.
- The relative humidity is 55-60% and the temperature is about 30-35 ° C before applying Dr.Fixit Multidor.
- Use a brush, roller or spatula on the desired surface.
- Apply a few more layers of multi-color paint.
- Dr.Fixit Multidor dries completely for 7 days before fully using it.

Cleaning

- Clean the equipment with water immediately after finish working.

Caution

- Do not add concrete or other into the product, Dr. Fixit Softbase 50
- Should be mixed in proportion to our guide.

Dr. Fixit Softbase 50

Modified Bitumen Emulsion

Technical Information

Properties	Standard/Testing Method	Result
Viscosity	-	15,000 – 17,000 Cps.
Solid content %	ASTM D2369	52-55
Density (kg/litre)	ASTM D70-03	1.32-1.34
Drying Time	Thickness ~ 1mm.Temp 30 °C humidity 55-60%	~ 1 hr.

Packing

Product	Packing
Dr. Fixit Softbase 50	18 Kg.

Storage

- 12 month in sealed container under shade and dry area.

Precaution and limitations

- Non-flammable, nontoxic.
- Avoid skin contact, it may cause skin irritation.
- In case of skin contacts wash off with water and soap.

Disclaimer

The product information and the recommendations relating to the application and end-use of Dr.Fixit products, are based on Dr.Fixit's current knowledge and experience of the products when properly stored, handled and applied under normal conditions in accordance with Dr.Fixit's recommendations. In practice, the differences in materials, substrates and actual site conditions are such that no warranty in respect of merchantability or of fitness for a particular purpose, nor any liability arising out of any legal relationship whatsoever, can be inferred either from this information, or from any written recommendations, or from any other advice offered. The user of the product must test the product's suitability for the intended application and purpose. Dr.Fixit reserves the right to change the properties of its products without notice, so the company does not assume liability of any legal from this product information.



Pidilite Bamco Limited (A group company of Pidilite Industries Ltd.)
 699 Modernform Tower 15,17 FL.,Srinakarin Rd.,Pattanakarn, Suan Luang, Bangkok 10250, THAILAND.
 T. +662 722-8535 F. +662 722-8381
 Website: www.dr-fixit.co.th
 E-mail: sales@pidilitebamco.com
 Helpline Call +662 722 8535 #101